Dual

Service-Anleitung
Service Manual
Instructions de Service

CT 5750

Dual
AM/FM STEREO TUNER CT 5750
POWER
AM/FM
FM SCAN
FM WIDE
MUTE OFF MONO
FM
93.50
MHz
FM SCAN
STEREO
SIGNAL
Audiophile Concept
MEMORY
TUNING

Technische Daten (typische Werte)	**Specifications** (typical values)	**Caractéristiques techniques** (valeurs types)	**Dati tecnici** (valori tipici)	**Dual CT 5750**
Empfangsbereiche FM (UKW) AM (MW) AM (USA/Canada)	**Reception wavebands** FM (VHF) AM (MW) AM (US/Canadian model)	**Games de fréquences** FM (OC) AM (OM) AM (Modèle USA/Canada)	**Campi di ricezione** FM (OUC) AM (onde medie) AM (Stati Uniti/Canada)	 87– 108 MHz 522–1611 kHz 520–1710 kHz
Empfindlichkeit (an 75 Ω) FM – Mono (26 dB) FM – Stereo (46 dB)	**Sensitivity** (at 75 Ω) FM – mono (26 dB) FM – stereo (46 dB)	**Sensibilité** (à 75 ohms) FM – Mono (26 dB) FM – Stéréo (46 dB)	**Sensibilità** (su 75 ohm) FM – mono (26 dB) FM – stereo (46 dB)	 0,8 µV 28 µV
Trennschärfe FM stat./dyn.	**FM selectivity** stat./dyn.	**Sélectivité** FM stat./dyn.	**Selettività** FM stat./din.	80/70 dB
Geräuschspannungsabstand	**Signal/noise ratio**	**Rapport signal/bruit**	**Rapporto segnale disturbo**	72 dB
Netzspannung Model Europa Model USA/Kanada Model UK	**Mains voltage** European model US/Canadian model UK model	**Voltage secteur** Modèle Europe Modèle USA/Canada Modèle Royaume-Uni	**Tensione di rete** modello Europa modello Stati Uniti/Canada modello GB	 220 V/50 Hz 120 V/60 Hz 240 V/50 Hz
Maße (Breite × Höhe × Tiefe)	**Dimensions** (width × height × depth)	**Dimensions** (largeur × hauteur × profondeur)	**Dimensioni** (larghezza × altezza × profondità)	 440 × 92 × 303 mm

Dual GmbH · Postfach 1144 · 7742 St. Georgen/Schwarzwald

921 619 0491

Copyright by Dual

Abgleichanleitung CT 5750

Signalquelle	Einstellung Gerät	Einstellung Signalquelle	Meßgerät Anschluß	Abgleichposition	Abgleich, Bemerkung
FM-Oszillator					
	87,5 MHz		DC Voltmeter an E und TP 3	L 107	1,5 V DC ± 0,1 V
	108 MHz			CT 104	9,0 V DC ± 0,1 V
				Abgleich wiederholen	
FM–ZF, Vorkreis					
FM-Meßsender an 75 Ohm Antenneneingang	Mono-Taste: Ein Senderfreie Frequenz ca. 98 MHz	0–1 mV Hub ± 40 kHz Mod. 1 kHz ca. 98 MHz auf Deckung	Klirrfaktormeßbrücke Oszilloskop an NF-Ausgang	L 106	NF-Maximum
				L 203 A	
				L 203 B	NF und Klirrfaktor Minimum
	90 MHz	ca. 90 MHz auf Deckung		L 102, L 103, L 104	NF-Maximum
	105 MHz	ca. 105 MHz auf Deckung		CT 101, CT 102, CT 103	
				Vorkreisabgleich wiederholen	
FM–ZF (Feinabgleich)					
Antenne an 75 Ohm Antenneneingang	Starken FM-Sender auf seiner Sollfrequenz empfangen		DC-Voltmeter an: TP 1–TP 2	L 203 B	DC-Maximum und DC-Minimum ermitteln
				L 203 B	Spannungsmitte einstellen
				L 203 A	0 V ± 1 mV DC
				Abgleich wiederholen	
Mono-, Stereo- und Muting-Übergang, Signalanzeige, Kanaltrennung					
FM-Meßsender an 75 Ohm Antenneneingang	Senderfreie Frequenz ca. 98 MHz Mono-Taste: Aus	ca. 98 MHz auf Deckung Hub ± 40 kHz, Mod. 1 kHz 19 kHz Pilot ein 6 µV	NF-Voltmeter, Oszilloskop an NF-Ausgang	VR 201	Mono-, Stereo- und Mutingübergang einstellen
				VR 202	Letzte Signal LED muß aufleuchten
		1 mV		VR 301	Maximale Kanaltrennung
Unterdrückung Pilottonreste (19 kHz)					
FM-Meßsender an 75 Ohm Antenneneingang	Senderfreie Frequenz ca. 98 MHz Mono-Taste: Aus	ca. 98 MHz auf Deckung 1–2 mV, 19 kHz Pilot ein	NF-Voltmeter Oszilloskop an NF-Ausgang	L 302 (l.K)	Minimum
				L 303 (r.K)	
LPF (114 kHz)					
NF-Generator	Aus	114 kHz 1 Vss an R 301	Oszilloskop an C 301	L 301	Minimum
AM-Oszillator					
	522 kHz		DC-Voltmeter an E – TP 3	L 202	1,4 V DC ± 0,1 V
	1611 kHz			CT 202	9,0 V DC ± 0,1 V
AM–ZF, Vorkreis					
AM-Meßsender an AM-Antenneneingang	999 kHz	10 µV–1 mV, 1 kHz, Mod. 30 % 999 kHz	NF-Voltmeter Oszilloskop an NF-Ausgang	L 204	Maximum
	594 kHz	594 kHz		L 201	
	1404 kHz	1404 kHz		CT 201	

Tuning Instructions for CT 5750

Signal source	Equipment setting	Signal source setting	Connection of measuring instrument	Item to be tuned	Tuning, Remarks
FM oscillator					
	87.5 MHz		DC voltmeter to E and TP 3	L 107	1.5 V DC ± 0.1 V
	108 MHz			CT 104	9.0 V DC ± 0.1 V
				Repeat tuning	
FM IF, input circuit					
FM signal generator to 75-ohm antenna input	Mono key: ON Frequency without transmitters approx. 98 MHz	0 - 1 mV, Shift ± 40 kHz Mod. 1 kHz Tune to approx. 98 MHz	Harmonic detector oscilloscope to AF output	L 106	AF maximum
				L 203 A	
				L 203 B	AF and harmonic distortion minimum
	90 MHz	Tune to approx. 90 MHz		L 102, L 103, L 104	AF maximum
	105 MHz	Tune to approx. 105 MHz		CT 101, CT 102, CT 103	
				Repeat input-circuit tuning	
FM IF (fine tuning)					
Antenna to 75-ohm antenna input	Receive strong FM transmitter at its nominal frequency		DC voltmeter to: TP 1 - TP 2	L 203 B	Determine DC maximum and DC minimum
				L 203 B	Adjust power mean
				L 203 A	0 V ± 1 mV DC
				Repeat tuning	
Transition between monaural, stereo and muting; signal indication, channel separation					
FM signal generator to 75-ohm antenna input	Frequency without transmitters approx. 98 MHz Mono key: OFF	Tune to approx. 98 MHz, Shift ± 40 kHz, Mod. 1 kHz, 19-kHz pilot ON, 6 µV	AF voltmeter, oscilloscope to AF output	VR 201	Set monaural, stereo and muting transition
		1 mV		VR 202	Last signal LED must light up
				VR 301	Maximum channel separation
Suppression of residual pilot frequencies (19 kHz)					
FM signal generator to 75-ohm antenna input	Frequency without transmitters approx. 98 MHz Mono key: OFF	Tune to approx. 98 MHz 1 - 2 mV, 19-kHz pilot ON	AF voltmeter, oscilloscope to AF output	L 302 (left channel)	Minimum
				L 303 (right channel)	
LPF (114 kHz)					
AF generator	OFF	114 kHz 1 Vpp to R 301	Oscilloscope to C 301	L 301	Minimum
AM oscillator					
	522 kHz		DC voltmeter to E - TP 3	L 202	1.4 V DC ± 0.1 V
	1611 kHz			CT 202	9.0 V DC ± 0.1 V
AM IF, input circuit					
AM signal generator to AM antenna input	999 kHz	10 µV - 1 mV, 1 kHz, Mod. 30% 999 kHz	AF voltmeter, oscilloscope to AF output	L 204	Maximum
	594 kHz	594 kHz		L 201	
	1404 kHz	1404 kHz		CT 201	



SCHEMATIC DIAGRAM MODEL CT5750 1/2 NOTE: PARTS AND CIRCUIT SUBJECT TO CHANGES FOR IMPROVEMENTS WITHOUT PRIOR NOTICE.


X-1146A01T
FM 75Ω
AM G
(FOR E ONLY)
(FOR U,C ONLY)
Q101 3SK107
Q102 3SK107
Q103 2SK544 / 2SK41
Q104 2SC1674
Q105 2SK544 / 2SK41
Q201 2SC1674
Q202 2SC1674
Q203 2SC1674
Q204 2SC536
Q205 2SK49
Q301 2SC1571
Q302 2SC536
Q303 2SA608
Q304 2SC2274
Q305 2SC2274
Q306 2SC536
Q307 2SC536
Q308 2SC536
Q401 2SC1571
Q402 2SC1571
Q403 2SK246Y
Q405 2SC536
Q406 2SA608
Q407 2SC536
Q408 2SA984
Q901 2SC2274
Q902 2SD600K
Q903 2SA984
IC201 LA1265
IC301 LA3400
IC302 NJM4558DD 1/2
IC302 2/2 NJM4558DD
IC401 TC9172P
IC402 LC4081B
IC901 NJM78M15
X205 SFE10.7MMH-A
X204 SFU107 MMH-A
X207 SFZ450G
L203 TRL342
L204 TRL343
L201 RLV129T
L202 RL150T
L302 TRL194
L303 TRL194
OUTPUT
(L)
(R)
TP1
TP2
TP3
TP4
VR201 50KB
VR202 100KB
X1146A03T
S901 POWER SW
J7
J8
J9
J10
J11
J10 TO J10 ON X1146A02T
TO J11 ON X-1146A02T
TO J9 ON X-1146A02T
S501 AM/FM
S502 FM SCAN
S503 FM WIDE
S504 MUTE OFF /MONO
X-1146A04T
T001 TT-224GF
AC120V (FOR U,C VERSION)
VOLTAGE SELECTOR
120V
220V
240V

LA3400


VOLT REG
OSC
PHASE COMPARATOR
PILOT DET
LAMP DRIVER
SYMMETRICAL REACTANCE CIRCUIT
VCO STOP
TRIGGER
FF
FF
FF 38KHz
FF 19KHz/90°
FF 19KHz/0°
STEREO SWITCH
A4
A3
DECODER
MUTING MUTING on/off FM/AM changed
MUTING OUTPUT
Ra
Rb
Rc
Rb
Rc
MUTING CKT
A1
A2
A8
A5
A6
A7
VCC ON MUTING

TC9303AN-001


VFL h g f e d c b a D6 D5 D4 D3 D2 D1 D0 K3 K2 K1 K0 GND
SEGMENT
DIGIT
KEY
I/O PORT
SERIAL I/O
3-1 3-2 3-3 3-4 2-1 2-2 2-3 2-4 1-2 Mute NC STB CK S0 S1 REF INT INH XT XT VDD

NJM4558DD


1
2
3
4
5
6
7
8
A
B

LC4081B


VDD IN IN OUT OUT IN IN
14 13 12 11 10 9 8
1 2 3 4 5 6 7
IN IN OUT OUT IN IN VSS


T001 TT-224GF
0V
120V
220V
240V
VOLTAGE SELECTOR
AC220V

(FOR E VERSION)

DESTINATION	DE-EMPHASIS	J501	J502	J503	J504
U.S.A	75uS	OPEN	CLOSE	CLOSE	CLOSE
EUROPE	50uS	CLOSE	OPEN	OPEN	CLOSE

DESTINATION	DE EMPHASIS	C312, 313	R243	X201	X202, 203
U.S.A	75uS	Ⓢ 750P	18K	10.7MLH-A	10,7MS 2GY
EUROPE	50 uS	Ⓢ 510P	27K	10.7MMH-A	10.7MS 3GY

SCHEMATIC DIAGRAM MODEL CT5750 2/2


J1
J2
J6
J4
J5
J3
D603 D604 D605 D606 D607
SIGNAL
D603–D607 : LTL 3237
IC601 TC9174P
C601 0.01
D601 LTL 3237
D602 LTL 3217
AUTO
STEREO
S601 M1
S602 M2
S603 M3
S604 M4
S605 M5
S606 M6
S607 M7
S608 M8
R602 47K
R601 47K
R604 47K
R603 47K
R605 47K
R606 47K
R607 47K
R608 47K
Q601 2SA608
Q602 2SA608
Q603 2SA608
Q604 2SA608
R609 330
R610 330
R612 330
R613 330
D628–D647 : IN4148
S609 M9
S610 M10
S611 M11
S612 M12
S613 M13
S614 M14
S615 M15
S616 M16
S621 MEMORY
S622 DOWN
S623 UP
S617 M17
S618 M18
S619 M19
S620 M20
D608–D627 : LTL13215A
X-1147A00T
TO J9 ON X-1146A01T
TO J11 ON X-1146A01T
TO J10 ON X-1146A01T
J9
J11
J6
J1
J10 J2
R514 330
R515 1K
R518 1K
R521 10
D501 IN4148
D502 IN4148
R501 10K
C501 6.3V 200
C502 0.047F
C503 0.047
C504 15P
C505 15P
X501 7.2MHz
D503 IN4148
R509 100K
C506 0.01
D536 IN4148
D508 IN4148
R510 47K
C514 0.01
R511 10K
R512 10K
R513 10K
R516 10K
R517 47K
Q505 2SA608
Q506 2SC3399
Q508 2SC3399
D513 IN4148
D514 IN4148
Q507 2SA608
Q509 2SA608
C515 50V1
R519 100K
R520 10K
C516 25V33
R522 10
C517 16V 220
IC502 LB1423N
016X-1146A02T
Q510, Q512–Q530 : 2SA608
2SA608
2SC3402
IN4148
D525–D535 : IN4148
Q511, Q513–Q531 : 2SC3402
Q501 2SC536
R502 47K
R503 47K
IC501 TC9303AN-001
R523 100K
J504 J503 J502 J501
D504 D505 D506 D507 IN4148
C513 0.01
Q502 2SA608
R504 47K
R505 10K
R506 47K
C512 0.01
C510 0.01
Q503 2SC536
R507 220K
D511 IN4148
C511 0.01
Q504 2SC536
R508 220K
D512 IN4148
D509 IN4148
D510 IN4148
D515 IN4148
D516 IN4148
D517 IN4148
D518 IN4148
D519 IN4148
D520 IN4148
D521 IN4148
D522 IN4148
D523 IN4148
D524 IN4148
Q510 D525 Q511
Q512 D526 Q513
Q514 D527 Q515
Q516 D528 Q517
Q518 D529 Q519
Q520 D530 Q521
Q522 D531 Q523
Q524 D532 Q525
Q526 D533 Q527
Q528 D534 Q529
Q530 D535 Q531
D537 RD6.2E
FL501 FIP7P8C
J4
J5
J3


2SA608K
2SC984K
2SC1674
2SC536
2SC1570
2SC2274
2SC3402
E B C
2SK49
G S D
2SK246Y
S G D
2SK41
2SK544
D S G
3SK107F
G2 D G1 S
2SD600K
E C B
LB1423N
TC9172P
TC9174P
LA3400
LA1265
LC4081B
TC9303AN-001
NJM4558DD



NJM78M12

1. OUTPUT
2. GND
3. INPUT

LB1423


AMP
1 2 3 4 5 6 7 8 9
VC1 VC2 VC3 VC4 GND VC5 AMP OUT IN VCC

TC9174P


CK SI SO I/O-10
STB
VDD
GND
I/O-1 (OP-1)
SERIAL I/O PROTECTOR
LATCH
LATCH
DRIVER
I/O-9
I/O-8
I/O-7
I/O-6
I/O-2 I/O-3 I/O-4 I/O-5

TC9172P


DO1 DO2 REF SI CK STB SO
AMP
PHFSE COMPARATOR
SIG
REF
SERIAL I/O PORT & PROTECTOR
4 BIT DATA BUSS
CORD BUSS
STROPE
INPUT
ASTP
IN1
φK17
OT1/(IN2)
OT2/(IN3)
OT3
OT4
OT5
OT6
OUTPUT PORT
φKL21
φKL22
COUNTER (10 BIT)
PLL I/O PORT
COUNTER 4 BIT
F/F
PSC
HF
LF
HF (LF)
1/15 / 1/16
PRESCALOR
FM
1/2
AM AM
IF COUNTER PROTECTOR PORT
IF COUNTER (15 Bit)
VDD
GND
TEST
AM
FMIN AMIN GND IFIN

LA1265


17 15 1 2 3 5 6 7 VCC
FM-IF
QD
POST AMP
10
LEVEL DIT
LEVEL DIT
CURVE
9
12
19
18
RF
MIX
AM-IF
DET
LED DRIVER
8
OSC
Buffer
REG
GND
AGC
METER
SD ADJ.
21 22 20 4 16 11 13 14

Tunerplatte
Tuner P.C.B.

Displayplatte
Display P.C.B.


016X-1146A01T
22M Ohm
OUTPUT
75 Ohm
E
TP1
TP2
TP3
AC1
AC2
AC3
AC7
AC6
E1
AC4
AC5
IC201
IC301
IC302
IC401
IC402
IC501
IC502
VR201
VR202
VR301
X207
X301
X501
L201
L203
L301
L302
L303
L901
J7
J8
J9
J10
J11
S501
S502
S503
S504
S901
04T
03T
02T

LED/Tastenplatte
LED P.C.B.


016E-1147A00T

Ersatzteile · Replacement parts · Pièces détachées · CT 5750

Pos.	Art.-Nr.	Bezeichnung
1	284 887	Frontblende CT 5750
2	284 519	Fenster
3	283 750	Dual-Zeichen
5	284 488	Taste
6	284 604	Tastenhalter 4-fach
7	284 487	Tastenführung
8	284 880	Druckfeder
8	284 515	Tastenverlängerung
10	284 886	Displayblende
11	284 490	Fenster
12	284 489	Taste 4-fach
13	284 606	Taste 3-fach
15	284 460	Fuß
16	284 448	Knopf
22	284 485	Schalter 4-fach
23	284 484	Netzschalter
24	286 500	Netztrafo
25	284 483	Anschlußklemme
26	284 533	Antennenbuchse
28	283 748	Spannungswahlschalter
30	243 750	Netzkabel Europa
31	283 742	Gehäuseblech
34	286 501	Halter
19		**LED / Tastenplatte**
IC 601	284 618	IC TC 9174
Q 601	284 506	Transistor 2 SA 608 K
bis		
Q 604	284 506	Transistor 2 SA 608 K
D 601	284 495	LED LTL 3227 A
bis		
D 607	284 495	LED LTL 3227 A
D 608	284 496	LED LTL 13215 A
bis		
D 627	284 496	LED LTL 13215 A
D 628	223 906	Diode 1 N 4148
bis		
D 647	223 906	Diode 1 N 4148
S 601	284 486	Schalter
bis		
S 627	284 486	Schalter
20		**Displayplatte**
C 502	284 516	Kondensator 5,5 / 0,047 F
D 501	223 906	Diode 1 N 4148
bis		
D 536	223 906	Diode 1 N 4148
D 537	274 006	Diode RD 6,2
Q 501	269 092	Transistor 2 SC 536 F, G
Q 502	284 506	Transistor 2 SA 608 K
Q 503	269 092	Transistor 2 SC 536 F, G
Q 504	269 092	Transistor 2 SC 536 F, G
Q 505	284 506	Transistor 2 SA 608 K
Q 506	284 511	Transistor 2 SC 3402
Q 507	284 506	Transistor 2 SA 608 K
Q 508	284 511	Transistor 2 SC 3402
Q 509	284 506	Transistor 2 SA 608 K
Q 510	284 506	Transistor 2 SA 608 K
Q 511	284 511	Transistor 2 SC 3402
Q 512	284 506	Transistor 2 SA 608 K
Q 513	284 511	Transistor 2 SC 3402
Q 514	284 506	Transistor 2 SA 608 K
Q 515	284 511	Transistor 2 SC 3402
Q 516	284 506	Transistor 2 SA 608 K
Q 517	284 511	Transistor 2 SC 3402
Q 518	284 506	Transistor 2 SA 608 K
Q 519	284 511	Transistor 2 SC 3402
Q 520	284 506	Transistor 2 SA 608 K
Q 521	284 511	Transistor 2 SC 3402
Q 522	284 506	Transistor 2 SA 608 K
Q 523	284 511	Transistor 2 SC 3402
Q 524	284 506	Transistor 2 SA 608 K
Q 525	284 511	Transistor 2 SC 3402
Q 526	284 506	Transistor 2 SA 608 K
Q 527	284 511	Transistor 2 SC 3402
Q 528	284 506	Transistor 2 SA 608 K
Q 529	284 511	Transistor 2 SC 3402
Q 530	284 506	Transistor 2 SA 608 K
Q 531	284 511	Transistor 2 SC 3402
IC 501	284 498	IC TC 9303
IC 502	284 499	IC LB 1423
X 501	284 503	Quarz 7,2 MHz
FL 501	284 497	**Display**

Pos.	Art.-Nr.	Bezeichnung
21		**Tunerplatte**
L 101	284 481	Filter Band Pass
L 102	284 468	Spule FM ANT
L 103	284 467	Spule FM RF
L 104	284 465	Spule FM RF
L 105	284 475	Spule
L 106	284 461	Spule FM IF
L 107	284 464	Spule FH OSC
Q 101	284 514	Transistor 3 SK 107 F
Q 102	284 514	Transistor 3 SK 107 F
Q 103	284 513	Transistor 2 SK 544
Q 104	284 510	Transistor 2 SC 1674 / LC 1674
Q 105	284 513	Transistor 2 SK 544
D 101	284 505	Diode SVC-202 AP
bis		
D 104	284 505	Diode SVC-202 AP
CT 101	284 478	Trimmer
bis		
CT 103	284 478	Trimmer
CT 104	284 479	Trimmer
IC 201	284 502	IC LA 1265
D 201	223 906	Diode 1 N 4148
bis		
D 205	223 906	Diode 1 N 4148
D 207	275 855	Diode SVC 321
D 208	275 855	Diode SVC 321
Q 201	284 510	Transistor 2 SC 1674 / LC 1674
bis		
Q 203	284 510	Transistor 2 SC 1674 / LC 1674
Q 204	269 092	Transistor 2 SC 536 F, G
Q 205	284 512	Transistor 2 SK 49
CT 201	284 478	Trimmer
CT 202	284 478	Trimmer
X 201	284 477	Keramik-Filter
X 202	284 480	Keramik-Filter
X 203	284 480	Keramik-Filter
X 202	284 569	Filter SFE 10,7 MS
X 203	284 569	Filter SFE 10,7 MS
X 204	284 477	Keramik-Filter
X 205	284 477	Keramik-Filter
X 206	284 473	Keramik-Filter
X 207	284 466	Keramik-Filter SFZ 450 G
L 201	284 472	Spule AM ANT
L 202	284 471	Spule AM OSC
L 203	284 469	Spule FM DET
L 204	284 470	Spule AM IF
D 301	223 906	Diode 1 N 4148
bis		
D 303	223 906	Diode 1 N 4148
D 304	282 021	Diode 1 N 4003
D 305	223 906	Diode 1 N 4148
D 306	223 906	Diode 1 N 4148
Q 301	284 509	Transistor 2 SC 1571
Q 302	269 092	Transistor 2 SC 536
Q 303	284 506	Transistor 2 SA 608 K
Q 304	284 508	Transistor 2 SC 2274
Q 305	284 508	Transistor 2 SC 2274
Q 306	269 092	Transistor 2 SC 536 F, G
bis		
Q 308	269 092	Transistor 2 SC 536 F, G
L 301	284 463	Spule MPX
L 302	284 462	Spule FM MPX
L 303	284 462	Spule FM MPX
X 301	284 474	Keramik-Filter
IC 301	283 385	IC LA 3400 N
IC 302	273 253	IC NJM 4558 D-D
Q 401	284 509	Transistor 2 SC 1570 / 1571
Q 402	284 509	Transistor 2 SC 1570 / 1571
Q 403	273 904	Transistor 2 SK 246 Y
Q 405	269 092	Transistor 2 SC 536 F, G
Q 406	284 506	Transistor 2 SA 608 K
Q 407	269 092	Transistor 2 SC 536 F, G
Q 408	284 507	Transistor 2 SA 984
D 401	223 906	Diode 1 N 4148
bis		
D 407	223 906	Diode 1 N 4148
IC 401	284 501	IC TC 9172 P
IC 402	284 500	IC TC 4081
D 901	282 021	Diode 1 N 4003
bis		
D 906	282 021	Diode 1 N 4003
D 907	274 006	Diode RD 6,2
D 908	284 504	Diode RD 18 E
D 909	274 006	Diode RD 6,2
D 910	282 021	Diode 1 N 4003

Änderungen vorbehalten! Subject to change! Sous réserve de modification!

Ersatzteile · Replacement parts · Pièces détachées · CT 5750

Pos.	Art.-Nr.	Bezeichnung
Q 901	284 508	Transistor 2 SC 2274
Q 902	282 002	Transistor 2 SD 600 / EGC 373
Q 903	284 507	Transistor 2 SA 984 K
IC 901	284 587	IC NJM 78 M 15
	284 482	Cinchbuchse

Pos.	Art.-Nr.	Bezeichnung
	284 662	Faltschachtel
	284 790	Styroporeinlage
	283 579	Bedienungsanleitung
	284 603	Antenne
	284 521	Hilfsantenne

Änderungen vorbehalten! Subject to change! Sous réserve de modification!



30
31
28
26
23
24
22
25
21
16
19
18
20
32
7
6
8
9
5
3
11
12
15
33
13
10
1
2